

NOTE: You will need a 1/8 to 1/8 cable and headphones for this camera.



Canon HF 10 Basic Instructions

From time to time we may need to use the old Canon cameras.

1. Insert battery. It will click when it is in place.



2. Set up microphone like you normally would. The difference is that you will be running an 1/8 cable into the camera, not XLR. Make sure that you have a 1/8 to 1/8 cable packed with your microphone. Insert it into the mic slot. It is the red input.



3. Plug in your headphones. They go into the yellow input.



4. Start and stop recording by using the red and silver record button.



